



# SWITCH DE ENCENDIDO



AUTO AND  
MOTOR PARTS  
**ELITESON**

# SWITCH DE ENCENDIDO



**AKT**

REF: 4020001  
SWITCH DE ENCENDIDO AK125 EVO/  
AK150 EVO



**AKT**

REF: 4020002  
SWITCH DE ENCENDIDO AK150TT



**AKT**

REF: 4020003  
SWITCH DE ENCENDIDO AK110  
SPECIAL



**AKT**

REF: 4020004  
SWITCH DE ENCENDIDO AK125 FLEX



**AKT**

REF: 4020005  
SWITCH DE ENCENDIDO AK125SL/  
AK125 NKD



**AKT**

REF: 4020006  
SWITCH DE ENCENDIDO AKT100



**SUZUKI**

REF: 4020007  
SWITCH DE ENCENDIDO GN125H



**SUZUKI**

REF: 4020008  
SWITCH DE ENCENDIDO TS125Z  
ERCN



**SUZUKI**

REF: 4020009  
SWITCH DE ENCENDIDO VIVA115/  
VIVAX 115

# SWITCH DE ENCENDIDO



**SUZUKI**

REF: 4020010  
SWITCH DE ENCENDIDO BEST125



**SUZUKI**

REF: 4020011  
SWITCH DE ENCENDIDO AX100  
-10WIRE



**SUZUKI**

REF: 4020012  
SWITCH DE ENCENDIDO AX100  
-11WIRE



**SUZUKI**

REF: 4020013  
SWITCH DE ENCENDIDO GS125/  
GSX150



**BAJAJ**

REF: 4020014  
SWITCH DE ENCENDIDO BOXER  
CT100/PLATINO 100



**BAJAJ**

REF: 4020015  
SWITCH DE ENCENDIDO BOXER  
BM100



**BAJAJ**

REF: 4020016  
SWITCH DE ENCENDIDO PULSAR 135



**BAJAJ**

REF: 4020017  
SWITCH DE ENCENDIDO PULSAR180  
DTS/DISCOVER100



**BAJAJ**

REF: 4020018  
SWITCH DE ENCENDIDO PLATINO 125

# SWITCH DE ENCENDIDO



**HONDA**

REF: 4020019  
SWITCH DE ENCENDIDO C90/CUB90



**HONDA**

REF: 4020020  
SWITCH DE ENCENDIDO WAVE 110



**HONDA**

REF: 4020021  
SWITCH DE ENCENDIDO CD100/ECO100



**HONDA**

REF: 4020022  
SWITCH DE ENCENDIDO CB125E  
/CGL125



**HONDA**

REF: 4020023  
SWITCH DE ENCENDIDO BIZ125



**HONDA**

REF: 4020024  
SWITCH DE ENCENDIDO BIZ100



**HONDA**

REF: 4020025  
SWITCH DE ENCENDIDO ECO DE LUXE



**HONDA**

REF: 4020026  
SWITCH DE ENCENDIDO CBF150



**HONDA**

REF: 4020027  
SWITCH DE ENCENDIDO XL185